



**Joinery
Products**

External Door Weather Strip WSTRIP

Application Instructions:

- 1) Measure each dimension of installed frame (head and vertical jambs).
- 2) Cut weather strips to length (weather strip can be cut with craft knife or scissors)
- 3) Install into frame as Diagram A
- 4) Once installed open and close door to check weather strip is secure and that door closes normally




Diagram A

- Helps prevent draughts by providing a compression seal between door and frame
- Easily applied into pre-cut grooves on all XL Joinery external door frames
- Easily trimmed to length (just use suitable craft knife or scissors)
- This weather strip is suitable for all frames up to an external frame size of 2107mm high and 1604mm wide

